


StoPowerwall™ NExT Protection of Rough Openings

Date: February 2009



Notes:

- 1] Prepare opening prior to the installation of the window or mechanical equipment.
- 2] Incorporate a sill wedge or shim to ensure slope to the front of the opening.
- 3] Incorporate flashing as illustrated in Sto Details 4.24cE, 4.24dE or 4.09E. Flashing should drain beyond finished cladding.
- 4] The complete installation of window or mechanical equipment should include an air seal connection between the object and StoGuard™ Waterproofing / Air Barrier. Provide the air seal connection inbound of the outer perimeter sealant joint. (See Sto Details 4.20E and 4.22E for examples.)

Attention

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, or for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components. **STO CORP. DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED EXCEPT FOR EXPLICIT LIMITED WRITTEN WARRANTIES ISSUED TO AND ACCEPTED BY BUILDING OWNERS IN ACCORDANCE WITH STO'S WARRANTY PROGRAMS WHICH ARE SUBJECT TO CHANGE FROM TIME TO TIME.** For the fullest, most current information on proper application, clean-up, mixing and other specifications and warranties, cautions and disclaimers, please refer to the Sto Corp. website, www.stocorp.com.