



# StoGuard™ Installation Checklist

## Contact Information

Contractor/Builder Company Name: \_\_\_\_\_

Contractor/Builder Contact: \_\_\_\_\_

Builder Phone: \_\_\_\_\_

Applicator Name: \_\_\_\_\_

Applicator Phone: \_\_\_\_\_

## Site Information

Project/Community/Subdivision: \_\_\_\_\_

Lot No.: \_\_\_\_\_

Street Address: \_\_\_\_\_

City, State, Zip: \_\_\_\_\_

Date Started: \_\_\_\_\_

Date Completed: \_\_\_\_\_

## Sheathing Application:

### Substrate

- Is the substrate clean, dry and free from damage, frost and all bond-inhibiting materials?
- Are sheathing gaps (if required) no more than a maximum of 1/8" (3 mm) at sheathing joints?
- Has attention been given to protecting adjacent areas before starting work?

## Air Barrier Component:

### Sheathing Joints

- If gaps are between 1/8" (3 mm) and 1/4" (25 mm) wide, was low expanding urethane foam used?
- Have the sheathing joints been treated with StoGuard joint treatment?

### Rough Openings

- Punched Studs should not be used in rough openings. If Punched Studs were used, was spray foam used to fill punched openings?
- Was StoGuard installed in the rough openings prior to windows being installed?
- Has head flashing been installed?
- Has sill flashing been installed?

### Fasteners

- Are all fasteners spotted – pre-coated?

## Waterproof Component:

### Sheathing Protection

- Is either Sto Gold Coat® or Sto EmeraldCoat® installed over sheathing at 10 wet mils?
- If using Sto Gold Coat over OSB, were 2 coats installed?

### Other items

- For EIFS installation, has starter track been installed?



# StoGuard™ Installation Checklist

## Concrete Masonry Unit Application:

### Substrate

- Have all the shrinkage cracks in mortar up to 1/8" (3 mm) been repaired with Gold Fill?
- Have all cracks greater than 1/8" (3 mm) been repaired with mortar, spray foam, sealant or StoGuard Tape?
- Has the first coat of Gold Coat or EmeraldCoat been applied 10-30 mils wet?
- Has the second coat of Gold Coat or EmeraldCoat been applied 10-30 mils wet?
- Did you make sure to back-roll between each coat?
- Have you achieved a void and pinhole free surface?

## Air Barrier Component:

### Rough Openings

- Was StoGuard installed in the rough openings prior to windows being installed?
- Has head flashing been installed?
- Has pan flashing been installed?

## Transitions between dissimilar materials:

- Has Sto Gold Coat, Sto EmeraldCoat or a primer been applied prior to the StoGuard Tape application?  
(this provides better adhesion)

#### ATTENTION

This product is intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. It should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, or for other construction activities beyond Sto's control. Improper use of this product or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to this product, and to the structure of the building or its components. **STO CORP. DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED EXCEPT FOR EXPLICIT LIMITED WRITTEN WARRANTIES ISSUED TO AND ACCEPTED BY BUILDING OWNERS IN ACCORDANCE WITH STO'S WARRANTY PROGRAMS WHICH ARE SUBJECT TO CHANGE FROM TIME TO TIME.** For the fullest, most current information on proper application, clean-up, mixing and other specifications and warranties, cautions and disclaimers, please refer to the Sto Corp. website, [www.stocorp.com](http://www.stocorp.com).

S806 07/08  
Printed in the U.S.A.