

StoGuard[®] Air and Water-Resistive Barrier

Design Guide and Detail Booklet Series 22s.xx | December 2022



Facades

StoGuard[®] is a water-based air and water-resistive barrier system, ideal for all types of construction and beneath multiple cladding types.

A fluid-applied system, StoGuard[®] forms a fully adhered and seamless monolithic air and water resistive barrier on the exterior wall, protecting against moisture intrusion and unwanted air movement. StoGuard[®] liquid membranes can be applied either by roller or airless sprayer, increasing the speed of application on the wall while simplifying integration with other wall assembly components.

Design Guide



Table of Contents

System Components	3
General Notes	4
StoGuard Product Use Chart	6
Guide Details	7



ATTENTION

The final design of any project is the sole responsibility of the Design Professional, with considerations for compliance with local building and design codes and requirements. Sto Corp. accepts no liability for design, engineering, or workmanship of any project.The information provided herein is in addition to other technical data provided by Sto Corp. (System Bulletin, Specification, Guide Details, etc). For more information, please visit www.stocorp.com

Sto Corp.

3800 Camp Creek Pkwy. SW Bldg. 1400 • Suite 120 Atlanta, GA 30331 Tel: (800) 221-2397 Fax: (404) 346-3119 http://www.stocorp.com helpdesk.stocorp.com

Components



Sto Gold Coat® - Roller or spray applied vapor-permeable air & water-resitive barrier designed for use in StoTherm[®] ci Systems.



Sto Gold Coat® TA - Trowel applied vapor-permeable air & water-resistive barrier for use behind siding, brick, stone, adhered veneer, and StoTherm[®] ci Systems.



Sto RapidGuard[®] - One-component air barrier and waterproof material used to protect rough openings, sheathing joints, seams, cracks, penetrations, and other transitions in above grade wall construction.



Sto AirSeal[®] - Roller or spray applied, medium-to-high build, vapor-permeable air & water-resistive barrier for use behind siding, brick, stone, adhered veneer, StoTherm[®] ci Systems, and other claddings.



StoGuard VaporSeal[®] - Roller or spray applied high build air barrier and Class 1 vapor retarder (< 0.1 perms). Provides superior protection against vapor diffusion, moisture intrustion, and air leakage.



Sto ExtraSeal[®] - Trowel applied, single component polymer modified portland cement-based water-resistive air barrier for use over prepared concrete and concrete masonry (CMU) walls.

Detail Component Products



Sto Gold Fill[®] - Trowel applied joint treatment and air barrier material used to treat rough openings, corners, and sheathing joints with StoGuard[®] Mesh or Sto Detail Mesh.



StoGuard® Fabric - Non-woven cloth reinforcement to treat joints, inside and outside corners and rough openings when embedded in Sto Gold Coat, Sto AirSeal or StoGuard® VaporSeal.

StoGuard® Mesh - Glass fiber, self-adhesive mesh for use with Sto Gold Fill and Sto Gold Coat TA as part of the StoGuard assembly.





StoGuard® RediCorner - A preformed StoGuard® fabric piece used in the corners of rough openings for quicker installation.



StoGuard® Conformable Membrane - A versatile, easy to install self-adhered membrane that simplifies detailing of transitions for air barrier continuity in Sto proprietary wall systems and other wall assemblies.



StoGuard® Transition Membrane - Flexible air barrier material used to make connections with adjoining construction to achieve continuity of the air barrier assembly at dynamic joints and dissimilar materials.

Structural - Wind and Axial Loads

- 1. Design for maximum allowable deflection normal to the plane of the wall of L/240 or as required by cladding (e.g., Brick L/720, Stucco L/360).
- 2. Design for wind load in conformance with code requirements.

Fire

- 1. <u>Non-Combustible Construction</u>: meets requirements for use on non-combustible construction based on testing in accordance with NPFA 285. Refer to ICC-ES ESR 1233 for allowable assemblies.
- 2. Fire-Resistant Rated Construction: Refer to ICC-ES ESR 1233 for allowable assemblies.
- 3. Refer to the Sto Tech Hotline No. 0111 BSc Fire Safety & Testing of Air Barriers and NFPA 285 Wall System Compliance Directory for more information.

Moisture Protection

- 1. Refer to Sto Tech Hotline No. 0603-BSc Moisture Control Principles for Design and Construction of Wall Assemblies and TH-0403-BSc, Critical Detail Checklist for Wall Assemblies for basic principles that must be employed in design and construction of wall assemblies to control moisture and to prevent water infiltration.
- 2. StoGuard functions as an air barrier and water-resistive barrier (WRB) in wall assemblies. The moisture protection provided by StoGuard protects walls against moisture damage from rain during the construction process and in the event of a breach in the wall cladding while in service. Flashing must always be integrated with the WRB in the wall assembly to direct water to the exterior of the cladding, not into the wall assembly, particularly at potential leak sources such as windows.
- 3. The function of an air barrier should not be confused with that of a vapor retarder. A vapor retarder is placed in the wall to resist differential vapor pressures, whereas the air barrier is designed to resist the structural live loads induced by air pressure difference.

Generally a vapor retarder is placed on the warm side of the wall. Specifically, it is placed on the interior side of the insulation in cold climates to minimize condensation within the wall assembly.

A vapor retarder may not be necessary depending on the wall components, the range of temperature/humidity conditions inside and outside, and the mechanical ventilation of the building. A vapor retarder should not be used on the interior side of walls in warm humid climates. Refer to applicable building codes for further guidance. If a vapor barrier is required refer to information on StoGuard VaporSeal products.

4. Some claddings, such as Portland Cement Stucco and Adhered Masonry Veneer require two layers of moisture protection and a path for drainage. Refer to Sto detail 22s.03 and local code requirements.

•

Regulatory Compliance

- 1. Complies with IBC, IRC and IECC as an air barrier material and water-resistive barrier (WRB). Refer to ICC-ES ESR 1233 for listed products.
- 2. Complies with VOC requirements of SCAQMD Rule 1113.
- 3. Complies with air barrier material requirements of ASHRAE 90.1 2013, 2016, 2019
- 4. Complies with air barrier material requirements of ASHRAE 189.1 2014, 2017
- 5. Complies with ABAA requirements for air barrier materials. Refer to ABAA website (www.airbarrier.org) for listed products.

Compatibility

1. All StoGuard[®] materials are adhesively and chemically compatible with one another. Verify compatibility of other air barrier materials, such as sealants, that come into contact with StoGuard[®] materials.

Other

- 1. Always construct a site built mock-up using materials and sub-trades associated with the project to verify installation, sequencing, detailing, and aesthetics, and test the performance of the window/wall assembly and other selected critical detail areas for air leakage, water infiltration, and structural adequacy in relation to design wind pressures. Correct any deficiencies shown by the mock-up and testing before commencing work.
- 2. Refer to product bulletins and specifications for complete information on Sto products. Refer to **StoGuard® Air and Water-Resistive Barrier Detail Series 22s.xx** for information on detailing with StoGuard products.
- 3. The final design of the project is the responsibility of the Design Professional. Sto accepts no liability for design, engineering, or workmanship of any project. The notes provided herein are in addition to Sto Guide Details, Guide Specifications, and other items available at www.stocorp.com

►	

Table 1.1 - StoGuard [®] Detail Component Applications						
				_		
StoGuard [®] Detail Component	Sheathing Joints and Corners	Flashing and Rough Opening Protection	Penetrations	Static Joints and Seams	Dynamic Joints	
Sto RapidGuard®	\checkmark	\checkmark	\checkmark	\checkmark		
StoGuard [®] Conformable Membrane	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	
StoGuard [®] Fluid Applied Air & Water-Resistive Barrier ¹ with StoGuard [®] Fabric	\checkmark	\checkmark	\checkmark			
StoGuard® Transition Membrane embedded with any StoGuard® Fluid Applied Air & Water-Resistive Barrier ¹				\checkmark	\checkmark	
Sto Gold Fill with StoGuard® Mesh (or Sto Detail Mesh embedded)	\checkmark	\checkmark	\checkmark			
Sto Gold Coat® TA with StoGuard® Mesh	\checkmark	\checkmark	\checkmark			

 $^{\rm 1}$ StoGuard® Fluid Applied Air & Water-Resistive Barriers: Sto AirSeal® and Sto Gold Coat®

Design Details

	onents	
	Components	22s.00
	Base of Wall - Masonry Ledge	. 22s.00A
	Oversized Sheathing Joint and Transition to Foundation	. 22s.00B
	Stucco or Adhered Masonry Veneer Cladding	
Install	ation at Grade	
	Termination at Grade: Sheathing Flush and Non-Flush with Foundation or Slab Edge	22s.00D
Install	ation with Furring, Drainage Mat, Stucco and Continuous Insulation	
	Frame Construction with Z-Furring	22s.01
	Sto DrainScreen [®]	22s.02
	Sto DrainScreen [®] and Code Compliant Paper or Felt WRB	
	Continuous Insulation and Brick Cavity Wall	
	y	
Install	ation for Rough Opening Protection	
	Rough Opening Protection with with StoGuard [®] Conformable Membrane	. 22s.20CM
	Rough Opening Protection with with StoGuard [®] Fabric	
	Rough Opening Protection with Sto Gold Fill [®] and StoGuard [®] Mesh	
	Rough Opening Protection with Sto RapidGuard [®]	
	Rough Opening Protection - Punched Stud	
		. 223.21
Install	ation at Windows	
	Box Window with Pan Flashing	22s 23D
	Nail Fin Window - Source Drainage	22s.23B
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical)	22s.23B 22s.24
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel	. 22s.23B . 22s.24 . 22s.25
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical)	. 22s.23B . 22s.24 . 22s.25
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical)	. 22s.23B . 22s.24 . 22s.25
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints	22s.23B 22s.24 22s.25 22s.26
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition	22s.23B 22s.24 22s.25 22s.26 . 22s.40
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track	22s.23B 22s.24 22s.25 22s.26 .22s.40 .22s.41
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition	22s.23B 22s.24 22s.25 22s.26 .22s.40 .22s.41
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle	22s.23B 22s.24 22s.25 22s.26 .22s.40 .22s.41
	Nail Fin Window - Source Drainage	22s.23B 22s.24 22s.25 22s.26 . 22s.40 . 22s.41 . 22s.42
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition	22s.23B 22s.24 22s.25 22s.26 . 22s.40 . 22s.41 . 22s.42 22s.43
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition Balcony Floor - Inside Corner	22s.23B 22s.24 22s.25 22s.26 22s.40 22s.41 22s.42 22s.42 22s.43 22s.43
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition Balcony Floor - Inside Corner Balcony Floor - Outside Corner	22s.23B 22s.24 22s.25 22s.26 22s.40 22s.41 22s.42 22s.43 22s.43A 22s.43B
	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition Balcony Floor - Inside Corner	22s.23B 22s.24 22s.25 22s.26 22s.40 22s.41 22s.42 22s.43 22s.43A 22s.43B
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition Balcony Floor - Inside Corner Balcony Floor - Outside Corner Balcony Ceiling to Wall Transition	22s.23B 22s.24 22s.25 22s.26 22s.40 22s.41 22s.42 22s.43 22s.43A 22s.43B
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition Balcony Floor - Inside Corner Balcony Floor - Outside Corner Balcony Ceiling to Wall Transition Balcony Ceiling to Wall Transition	22s.23B 22s.24 22s.25 22s.26 22s.40 22s.41 22s.42 22s.43 22s.43A 22s.43B 22s.43B 22s.44
Install	Nail Fin Window - Source Drainage	22s.23B 22s.24 22s.25 22s.26 . 22s.40 . 22s.41 . 22s.42 22s.43 22s.43A . 22s.43B 22s.43B 22s.44
Install	Nail Fin Window - Source Drainage Window Head Flashing - Flanged Window (Typical) Window Head Flashing with Lintel Window Head Flashing - Box Window (Typical) ation at Joints Floor Line at Fixed Slab-to-Frame Condition Floor Line with Deflection Track Floor Line with Deflection Track and Shelf Angle ation at Balcony/Abutments Balcony Floor to Wall Transition Balcony Floor - Inside Corner Balcony Floor - Outside Corner Balcony Ceiling to Wall Transition Balcony Ceiling to Wall Transition	22s.23B 22s.24 22s.25 22s.26 . 22s.40 . 22s.41 . 22s.42 22s.43 22s.43A . 22s.43B 22s.43B 22s.44
Install	Nail Fin Window - Source Drainage	22s.23B 22s.24 22s.25 22s.26 . 22s.40 . 22s.41 . 22s.42 22s.43 22s.43A . 22s.43B 22s.43B 22s.44

۱

Design Details (cont'd)

Installation at Corners


	Outside Corner Inside Corner	22s.54 22s.55
Installa	ation at Parapets, Gravel Stop, Roofline Termination at Parapet Saddle Flashing at Lower/Higher Wall Abutment	
Installa	ation at Penetrations Pipe Penetration - Pipe Penetration with Minor Gap Fixture Attachment Scupper Penetration	22s.73

١



StoGuard[®] Air and Water-Resistive Barrier Components

Detail No.: 22s.00 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Base of Wall - Masonry Ledge

Detail No.: 22s.00A Date: December 2022




ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure of the building or its components.



StoGuard® Air and Water-Resistive Barrier Oversized Sheathing Joint and Transition to Foundation

Detail No.: 22s.00B Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier for Stucco or Adhered Masonry Veneer Cladding

Detail No.: 22s.00C Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] StoGuard[®] Air and Water-Resistive Barrier Termination at Grade Sheathing Flush with Foundation or Slab Edge

Detail No.: 22s.00D Date: December 2022 Page 1 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] StoGuard[®] Air and Water-Resistive Barrier Termination at Grade Sheathing Overlapping Foundation or Slab Edge

Detail No.: 22s.00D Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Frame Construction with Z-Furring

Detail No.: 22s.01 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier with Sto DrainScreen[®]

Detail No.: 22s.02 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier with Sto DrainScreen[®] and Code Compliant Paper or Felt WRB

Detail No.: 22s.03 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier with Continuous Insulation and Brick Cavity Wall

Detail No.: 22s.04 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier **Rough Opening Protection** StoGuard[®] Conformable Membrane

Detail No.: 22s.20CM Date: December 2022 Page 1 of 3




qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier **Rough Opening Protection** StoGuard[®] Conformable Membrane

Detail No.: 22s.20CM Date: December 2022 Page 2 of 3



ATTENTION

Property of Sto Corp. All Rights Reserved.

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components





StoGuard[®] Air and Water-Resistive Barrier Rough Opening Protection StoGuard[®] Conformable Membrane

Detail No.: 22s.20CM Date: December 2022 Page 3 of 3



Notes:

1. Refer to StoGuard® Detail Component Applications (Table 1.1) for StoGuard detail components; joint treatment, rough opening protection, backing for masonry anchors, or transitions to dissimilar materials, joints and seams in construction.

2. Refer to General Notes for specific information and design guidance on wall assembly components.

3. Glass mat gypsum sheathing in compliance with ASTM C1177, exterior grade and Exposure 1 wood based sheathing, or cementitious sheathing in compliance with ASTM C1325.

4. Incorporate flashing as illustrated in Details 22s.23 through 22s.24, or as per other details where flashing is shown. Provide sill wedge or other means for positive slope to exterior at sill.

5. The complete installation of window or mechanical equipment must include an air seal between the object and the StoGuard protection, inbound of the outer perimeter weather seal.

6. Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

www.stocorp.com



ATTENTION

Property of Sto Corp. All Rights Reserved.

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.



StoGuard[®] Air and Water-Resistive Barrier **Rough Opening Protection with StoGuard®Fabric**


Detail No.: 22s.20F Date: December 2022 Page 1 of 2


STEP 1

Apply StoGuard[®] Air & Water Resistive Barrier liberally at the corners of rough openings and place StoGuard[®] RediCorners[®] in wet material. Fully embed the StoGuard® RediCorner[™] by top coating with additional StoGuard® Air & Water Resistive Barrier.

> StoGuard[®] Fabric embedded in StoGuard® Air & Water-Resistive Barrier at sheathing joints (See Note 1)

NOTE: When using StoGuard[®] RediCorner[®] in a rough opening deeper than 2 inches by 4 inches use a strip of StoGuard[®] Fabric along framing joint to full depth of opening at the sill-to-jamb and jamb-to-head intersections embedded in StoGuard® Air & Water-Resistive Barrier.





STEP 2

Apply StoGuard[®] Air & Water Resistive Barrier liberally to inside of opening and around outside of head, sill and jambs.

Property of Sto Corp. All Rights Reserved.

Notes:

1. Refer to StoGuard[®] Detail **Component Applications** (Table 1.1) for StoGuard detail components; joint treatment, rough opening protection, backing for masonry anchors, or transitions to dissimilar materials, joints and seams in construction.

2. Refer to General Notes for specific information and design guidance on wall assembly components.

3. Glass mat gypsum sheathing in compliance with ASTM C1177, exterior grade and Exposure 1 wood based sheathing, or cementitious sheathing in compliance with ASTM C1325.

4. Incorporate flashing as illustrated in Details 22s.23 through 22s.24, or as per other details where flashing is shown. Provide sill wedge or other means for positive slope to exterior at sill.

5. The complete installation of window or mechanical equipment must include an air seal between the object and the StoGuard protection, inbound of the outer perimeter weather seal.

6. Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

www.stocorp.com



Center StoGuard® Fabric on outside corners and press into wet membrane along the head, jambs, and sill with minimum 2" (50 mm) overlaps of adjacent fabric. Fully embed StoGuard[®] Fabric by top coating with additional StoGuard® Air & Water-Resistive Barrier.


ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.

StoGuard® Air and Water-Resistive Barrier Rough Opening Protection with StoGuard®Fabric

sto

Detail No.: 22s.20F Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Rough Opening Protection with Sto Gold Fill[®] and StoGuard[®]Mesh

Detail No.: 22s.20M Date: December 2022 Page 1 of 2



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.

STO CORP. DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED EXCEPT FOR EXPLICIT LIMITED WRITTEN WARRANTIES ISSUED TO AND ACCEPTED BY BUILDING OWNERS IN ACCORDANCE WITH STO'S WARRANTY PROGRAMS WHICH ARE SUBJECT TO CHANGE FROM TIME TO TIME. For the fullest, most current information on proper application, clean-up, mixing and other specifications and warranties, cautions and disclaimers, please refer to the Sto Corp. website, www.stocorp.com.

1. Refer to StoGuard[®] Detail **Component Applications** (Table 1.1) for StoGuard detail components; joint treatment, rough opening protection, backing for masonry anchors, or transitions to dissimilar materials, joints and seams in construction.

2. Refer to General Notes for specific information and design guidance on wall assembly components.

3. Glass mat gypsum sheathing in compliance with ASTM C1177, exterior grade and Exposure 1 wood based sheathing, or cementitious sheathing in compliance with ASTM C1325.

4. Incorporate flashing as illustrated in Details 22s.23 through 22s.24, or as per other details where flashing is shown. Provide sill wedge or other means for positive slope to exterior at sill.

5. The complete installation of window or mechanical equipment must include an air seal between the object and the StoGuard protection, inbound of the outer perimeter weather seal.

6. Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.


www.stocorp.com





StoGuard[®] Air and Water-Resistive Barrier Rough Opening Protection with Sto Gold Fill[®] and StoGuard[®]Mesh

Detail No.: 22s.20M Date: December 2022 Page 2 of 2



www.stocorp.com


ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.



StoGuard® Air and Water-Resistive Barrier Rough Opening Protection with Sto RapidGuard®

Detail No.: 22s.20RG Date: December 2022 Page 1 of 2



Notes:

1. Refer to StoGuard® Detail Component Applications (Table 1.1) for StoGuard detail components; joint treatment, rough opening protection, backing for masonry anchors, or transitions to dissimilar materials, joints and seams in construction.

2. Refer to General Notes for specific information and design guidance on wall assembly components.

3. Glass mat gypsum sheathing in compliance with ASTM C1177, exterior grade and Exposure 1 wood based sheathing, or cementitious sheathing in compliance with ASTM C1325.

4. Incorporate flashing as illustrated in Details 22s.23 through 22s.24, or as per other details where flashing is shown. Provide sill wedge or other means for postive slope to exterior at sill.

5. The complete installation of window or mechanical equipment must include an air seal between the object and the StoGuard protection, inbound of the outer perimeter weather seal.

6. Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

www.stocorp.com




ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.



StoGuard[®] Air and Water-Resistive Barrier Rough Opening Protection with Sto RapidGuard[®]

Detail No.: 22s.20RG Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier **Rough Opening Protection - Punched Stud**

Detail No.: 22s.21 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Box Window with Pan Flashing

Detail No.: 22s.23A Date: December 2022 Page 1 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure during may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Box Window with Pan Flashing

Detail No.: 22s.23A Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Nail Fin Window - Source Drainage

Detail No.: 22s.23B Date: December 2022 Page 1 of 3



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Nail Fin Window - Source Drainage

Detail No.: 22s.23B Date: December 2022 Page 2 of 3



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Nail Fin Window - Source Drainage

(Optional) StoGuard Detail Component lapped onto window flange along jambs. Extend nominal

Detail No.: 22s.23B Date: December 2022 Page 3 of 3

<u>Notes:</u>

1. Refer to StoGuard® Detail Component Applications (Table 1.1) for StoGuard detail components; joint treatment, rough opening protection, backing for masonry anchors, or transitions to dissimilar materials, joints and seams in construction.

2. Refer to General Notes for specific information and design guidance on wall assembly components.

3. Glass mat gypsum sheathing in compliance with ASTM C1177, exterior grade and Exposure 1 wood based sheathing, or cementitious sheathing in compliance with ASTM C1325.

4. Provide sill wedge or other means of positive slope to exterior at sill.

5. The complete installation of window or mechanical equipment must include an air seal between the object and the StoGuard protection, inbound of the outer perimeter weather seal.

6. Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

1" (25 mm) minimum onto surface of wall. Do not apply to bottom flange of window. Sealant **Inset Detail** Flanged-Nail Fin Window Interior Air Seal Metal Frame See Inset Detail StoGuard® Air & Water-Resistive Barrier

ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.

STO CORP. DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED EXCEPT FOR EXPLICIT LIMITED WRITTEN WARRANTIES ISSUED TO AND ACCEPTED BY BUILDING OWNERS IN ACCORDANCE WITH STO'S WARRANTY PROGRAMS WHICH ARE SUBJECT TO CHANGE FROM TIME TO TIME. For the fullest, most current information on proper application, clean-up, mixing and other specifications and warranties, cautions and disclaimers, please refer to the Sto Corp. website, www.stocorp.com.




www.stocorp.com

Property of Sto Corp. All Rights Reserved



StoGuard® Air and Water-Resistive Barrier Window Head Flashing - Flanged Window (Typical)

Detail No.: 22s.24 Date: December 2022 Page 1 of 2



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.






Detail No.: 22s.24

Page 2 of 2

Date: December 2022

StoGuard® Air and Water-Resistive Barrier Window Head Flashing - Flanged Window (Typical)



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





Page 1 of 2

Detail No.: 22s.25

Date: December 2022

StoGuard® Air and Water-Resistive Barrier Window Head Flashing with Lintel

Stud Cavity Insulation Notes: STEP 1 1. Refer to StoGuard[®] Detail Installation of Lintel **Component Applications** (Table 1.1) for StoGuard detail components; joint treatment, StoGuard[®] rough opening protection, Air & Water-Resistive Barrier backing for masonry anchors, or transitions to dissimilar materials, joints and seams in construction. StoGuard® Detail Component (See Note 1) 2. Refer to General Notes for specific information and design guidance on wall assembly components. Metal Frame 3. Glass mat gypsum sheathing in compliance with ASTM C1177, exterior grade and Exposure 1 wood based Structural Steel Lintel sheathing, or cementitious sheathing in compliance with ASTM C1325. Sheathing (See Note 3) STEP 2 4. The complete installation of window or mechanical Installation of StoGuard® equipment must include an air **Detail Component over** seal between the object and Flashing the StoGuard protection, inbound of the outer perime-StoGuard[®] Detail Component ter weather seal. (See Note 1) 5. Components not identified as Sto are furnished by other StoGuard[®] manufacturers and are not Air & Water-Resistive Barrier necessarily installed by trades who install the Sto products. Refer to project specific contract documents. Metal Frame Sealant Flashing with End Dams Property of Sto Corp. All Rights Reserved. www.stocorp.com

ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Window Head Flashing with Lintel

Detail No.: 22s.25 Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Window Head Flashing - Box Window (Typical)

Detail No.: 22s.26 Date: December 2022 Page 1 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Window Head Flashing - Box Window (Typical)

Detail No.: 22s.26 Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Floor Line at Fixed Slab-to-Frame Condition

Detail No.: 22s.40 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Floor Line with Deflection Track

Detail No.: 22s.41 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Floor Line with Deflection Track and Shelf Angle

Detail No.: 22s.42 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Balcony Floor to Wall Transition

Detail No.: 22s.43 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Balcony Floor - Inside Corner

Detail No.: 22s.43A Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Balcony Floor - Outside Corner

Detail No.: 22s.43B Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Balcony Ceiling to Wall Transition

Detail No.: 22s.44 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Vertical Expansion Joint in Back-Up Wall

Detail No.: 22s.52 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Inside Corner - Dissimilar Substrates

Detail No.: 22s.53 Date: December 2022



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure during may result in serious damage to Sto products, and to the structure of the building or its components.








StoGuard® Air and Water-Resistive Barrier Outside Corner

Detail No.: 22s.54 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Inside Corner

Detail No.: 22s.55 Date: December 2022



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructure of the building or its components.








StoGuard[®] Air and Water-Resistive Barrier Termination at Parapet

Detail No.: 22s.60 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard[®] Air and Water-Resistive Barrier Saddle (Low-to-High) Wall Intersection

Detail No.: 22s.64 Date: December 2022



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.








StoGuard® Air and Water-Resistive Barrier Pipe Penetration

Detail No.: 22s.70 Date: December 2022 Page 1 of 2



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.








StoGuard® Air and Water-Resistive Barrier Pipe Penetration with Minor Gap

Detail No.: 22s.70 Date: December 2022 Page 2 of 2



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Fixture Attachment

Detail No.: 22s.73 Date: December 2022



ATTENTION


Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.





StoGuard® Air and Water-Resistive Barrier Scupper Penetration

Detail No.: 22s.75 Date: December 2022



ATTENTION

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.

STO CORP. DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED EXCEPT FOR EXPLICIT LIMITED WRITTEN WARRANTIES ISSUED TO AND ACCEPTED BY BUILDING OWNERS IN ACCORDANCE WITH STO'S WARRANTY PROGRAMS WHICH ARE SUBJECT TO CHANGE FROM TIME TO TIME. For the fullest, most current information on proper application, clean-up, mixing and other specifications and warranties, cautions and disclaimers, please refer to the Sto Corp. website, www.stocorp.com. www.stocorp.com

